



- Adjustment of clearance between hinge jamb and door stile: Loosen screws (B) and (C).
- Adjustment of door height: Loosen screws (B), (C), and adjust screw (A).
- Centering door: Loosen screws (B) and (C).
- Adjustment of closing speed: -Two regulating valves (D) and (E).

- Adjustment of closing speed:
  - (⊖) decrease closing speed.
  - (⊕) increase closing speed.
- Adjustment of closing range:
  - Valve (D): control closing range 180°-15°
  - Valve (E): control closing range 15°-0°
- Adjustment of spring tension (F):
  - (⊕) increase spring tension
  - (⊖) decrease spring tension

